


# Instructions to activate the Rapid palatal Expander:





## Step 1

*In a well-lit area, tip the child's head backwards. The higher their chin is, the easier it will be for you to see the hole.*

## Step 2

*Place the key into the hole until it is firmly in place.*




## Step 3



*Push the key towards the back of the mouth. You will notice the center cog has turned and a new hole has appeared. The rotation stops when the key meets the back of the expander.*



## Step 4

*Slowly remove the key from the hole by pushing the key straight down and out of the hole. Be careful not to accidentally unwind the expander while removing the key. The next hole should still be visible after removing the key.*



Follow your doctor's instructions for maximum instructions for maximum allowed. Record the number of activations completed:

DATE		

DATE		

DATE	